




Náhradní díl pro / spare part for / Ersatzteil für: TASI 154113012, OMEGA 104113102, 104113012, 104836012, 104913152, 104913122, 104913112, 104913092, 104113017, 104913152, 104913122, 104913117, 104913092, 104113107, BETA 132113012, 132113017, VIA

Parametry / Features / Eigenschaften

šířka / width / Breite:	70 mm
výška / height / Höhe:	355 mm
hloubka / depth / Tiefe:	70 mm
materiál / material / Material:	nerez, guma / stainless steel, rubber / Edelstahl, Gumm
povrch. úprava / finish / Oberfläche:	chrom / chrome / Chrom
kartáč / brush / Bürste:	černá / black / schwarz